



# PVC SPRAY 'N LOCK™

**BONDS WET AND DRY PVC, CPVC, ABS AND SWV PIPES AND MATERIAL**

Specially designed for contractors that need a better, faster and easier way to build and repair non-potable PVC systems, Spray-N-Lock makes the impossible a practical reality. Simply spray on both pipe and fittings and push together. Immediately the product goes to work, bonding the material on a molecular level. Within seconds\* the bond becomes permanent. No daubers, primers or cement required. **One can does it all.**



## Available in Industry Purple and Professional Clear

- Easy Aerosol Application
- Quickly Bonds Similar Components
- Works in Rain, Sleet and Snow
- Will not Freeze, Spill or Dry Out in Can
- Fuses Wet or Dry Material in Seconds
- MultiPurpose
- All Weather
- No Waste
- Sprays On In Seconds
- Long Shelf Life

**PVC Spray-N-Lock Purple** dries inspection purple, ensuring quick and easy visual confirmation of application. It's perfect for contractors that need an easy way for inspectors to see that their PVC pipes are professionally bonded. PVC Spray-N-Lock purple leaves an undeniable, permanent purple color on all sprayed joints and surfaces.

**PVC Spray-N-Lock Clear** dries completely clear, leaving little to no indication a bonding solution was used for a cleaner look when no inspection is necessary. *To help with inspections, both products dissolve and fade any printed ink on sprayed piping.*

## APPLICATION/SPECIFICATIONS

PVC Spray-N-Lock bonds PVC, CPVC, ABS and SWV material on a molecular level quickly creating a permanent bond. PVC Spray-N-Lock has been pressure tested up to 120 PSI, can not spill and will not dry out in the can. It's great for all projects no matter the weather or working conditions and does not require a pliers to open or close. It works on both wet and dry material and will not freeze. It is NOT certified for potable water systems.

- Electrical conduits
- Ventilation Pipes
- Irrigation Lines
- Sewage, Waste and Drainage Systems
- Swimming Pool Pipes
- Lawn and Garden Areas
- Home and Hobby Projects



## DIRECTIONS

Read and understand all warnings and directions before use. As per use with any flammable substance, take adequate precautions during use.

- 1) Cut pipe square.
- 2) Remove dirt and burrs.
- 3) Dry fit pipe into fitting.
- 4) Mark pipe for alignment.
- 5) Spray pipe and fitting.
- 6) Insert pipe into fitting.
- 7) Turn pipe 1/4 turn.
- 8) Hold pipe for 10 seconds.
- 9) Follow the directions love for the remainder of the joints.

**Note:** Product dries rapidly. Make sure PVC pipe and fitting are wet with product on all sides before connecting.

- Recommended Installation: 50°F +
- Recommended for use on pipe 2" and under.
- Not certified for use on potable water systems.
- Product designed to bond similar PVC components.
- **Results vary if dissimilar types are used.**

## ALL WEATHER FORMULA

**PVC Spray-N-Lock** works great in inclement weather (rain, sleet and snow) and shines through in tough, tight challenging conditions. Keep in mind that set times will vary based on temperature and humidity. Please allow more time for the product to set should it be cold or hot.



## RECOMMENDED SET TIMES

Temperature Range*	Pip Sizes 1/2" to 2"
60° - 100°F	1 min.
40° - 60°F	5 min
0° - 40°	10 min

*\*Set times vary depending on temperature and humidity. If in doubt, allow more time to cure.*

**Follow All Directions and Safety Precautions**

**DO NOT ALLOW CHILDREN TO USE PRODUCT**

SDS/TDR available at Website

